## Water Block Wax P&M

00344 **EN** 

Vater Res (1804 Super Spase) was developed with one goal in mind: extreme hydrophobicity. The unique formula based on wrater lost (since polymers a flow) water to be repelled from the spainwork in a flash, which effectively between the adherence of dirt and makes it much lost sick in care (clean. Water Block is characteristic by easy application and great durability: maker that with the since in the spain of the spain

Directions: L Prepare the vehicle by washing it with a pH-neutral shampoo, drying it; deaning its surface using a clay bar, deaner or other product of this kind, 2, Apply the wax to the supplied sponge by lightly rubbing it on the wax's surface. 3. Spread a thin and even layer of wax on the paintwork, pressing lightly. 4. Wait until white residue appears on the paintwork, 5. Polish the residue with a dean and dry microfiber cloth, ! Never apply wax in direct sunlight or on hot components.

Contains: hydrocarbons, C9-C12, n-alkanes, isoalkanes, cyclics, aromatics (2-25%).

Flammable solid. Causes skin iritation. May cause drowsiness or dizziness. Toxic to aquatic life with long lasting effects. Keep out of reach of children. Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking, Avoid release to the environment. Wear protective gloves frontective dothing, IF ON SKINI. Wash with liertly of water and soap. IF NN HALED. Remove person to fresh air and keep comfortable for breathing, Dispose of contents/contained to protective liabelled waste containers according to national law.

## LIFE: F IXO-202S-KOOD-DV7F

DANGER







MADE IN JAPAN



T. +48 691 344 348, info@soft99.eu

Importer: Nowy Samochód SA, ul. Zbyszka Cybulskiego 3, 00-725 Warszawa, Polska.

